

Installation and Maintenance Instructions

Apinox Product Code 255 Inset Wash Basin

Installation

The wash basin is designed for in setting into counter tops up to 50mm thick.

Make a 295mm cut out for the basin.

Place the basin into the cut out and mark the tap hole centres through the basin tap holes on to the worktop.

Remove the basin and drill tap holes to the required diameters

A suitable sealant should be applied to the underside of the basin / surface of the worktop before fitting

Secure the basin using the studs and nuts supplied

Fit the supplied waste fitting and complete the remainder of the plumbing installation.

Maintenance

Routine cleaning is necessary to maintain the appearance of stainless steel. Washing with soap or a mild detergent and warm water, applied with a sponge or bristle brush, followed by a clear water rinse is all that is required.

For further information please see our 'Care and Maintenance of Stainless Steel' leaflet