

Installation and Maintenance Instructions

Apinox Product Code 273 Inset Medical / Dental Basin

Installation

The wash basin is designed for inseting into counter tops up to 50mm thick.

Make a cut out either 305mm in diameter for basins with overall diameter 330mm or of 365mm diameter for basins with overall diameter 390mm

A suitable sealant should be applied to the underside of the bowl / surface of the worktop before fitting.

Fit the supplied waste and complete the remainder of the plumbing installation.

Maintenance

Routine cleaning is necessary to maintain the appearance of stainless steel. Washing with soap or a mild detergent and warm water, applied with a sponge or bristle brush, followed by a clear water rinse is all that is required.

For further information please see our 'Care and Maintenance of Stainless Steel' leaflet